
HENRY One Hole Bidet Fitting with Metal Cross Handles

STYLE No. HNBF01⁺



SPECIFICATIONS:

Adjustable versus Fixed Spray: Fixed Spray Deck Thickness Maximum: 1-5/8" [41mm] Drain Depth: 1-1/2" [38mm] MIN - 1-7/8" [48mm] MAX Drain Hole Diameter: 1-3/4" [44mm] Drain Style: Pop-up Fittings Hole Diameter: Ø1-1/4" [32mm] Inlet Connection: 3/8" O.D. Supply Tubing † Pivot: Yes Restricted Maximum Flow Rate: 2.2gpm [8.3L/m] Spout Reach: 4-1/8" [105mm] Water Pressure Minimum: 20psi [1.5bar] Water Pressure Maximum: 85psi [6.0bar] Water Pressure Recommended: 45psi [3.0bar]

⁺ UK Style No. HN01BF is supplied with 10mm O.D. Supply Tubes.

IMPORTANT:

- To ensure this product is installed properly, you must read and follow these guidelines.
- The owner/user of this product must keep this information for future reference.
- This product must be installed by a professional licensed contractor.
- Ensure the installation conforms to all federal, state, and local codes. In the State of Massachusetts, all installations must comply with the rules and regulations set forth within 248 CMR.
- Inspect this product to ensure you have all the parts required for proper installation.
- Use only a strap wrench or protected/smooth-jaw wrench on any finished surface.

Installation Guidelines

DO NOT use putty. Putty contains oils and can cause permanent discoloration on certain materials such as marble, granite and any porous surface

SPOUT INSTALLATION:

Reference Figure - 01 for Steps 1 - 4.




FIGURE - 01

- 1. Remove the barrel nut, metal washer and black rubber washer. Do NOT remove the threaded rod.
- 2. With the supply tubes and lift rod assembly installed, insert the bidet assembly through the hole on the mounting surface. Make sure the white rubber washer is between the spout and the mounting surface.
- 3. Re-attach the black rubber and metal washers onto the threaded rod, making sure the supply tubes are not pinched and the lift rod operates smoothly through the opening on the metal washer.
- 4. Re-attach the barrel nut to the threaded rod and securely tighten.

DRAIN INSTALLATION:

Reference Figure - 02 for Steps 5 - 11.

These guidelines have been prepared for the professional contractor to aid in the installation of: <u>HENRY ONE HOLE BIDET FITTING WITH METAL CROSS HANDLES (STYLE No. HNBF01, HN01BF)</u>. All dimensions are based on original specification and are subject to change and variation. Please consult your Design Associate for current specifications.

WATERWORKS




FIGURE - 02

- 5. Remove the drain flange from the lower drain body. The foam washer can be discarded.
- 6. Set the drain flange in the drain opening of the bidet using a clear adhesive silicone.
- 7. Re-attach the lower drain body using the lower drain gasket provided and tighten until fully secured. A clear adhesive silicone may be used to ensure a water-tight seal between the gasket and bidet.
- 8. Remove the knurled nut from the lower drain body and insert the horizontal pivot rod and re-attach the knurled nut. Make sure to include the plastic bushing.
- 9. Connect the lift rod to the horizontal pivot rod using the pivot joint provided.

NOTE: Both rods may be field cut.

- 10. Attach the tailpiece to the lower drain body using the rubber washer and tailpiece nut provided.
- Connect the tailpiece to the p-trap (not supplied) and the supply tubes to the supply valves (not supplied) based on the rough-in specifications.

These guidelines have been prepared for the professional contractor to aid in the installation of: <u>HENRY ONE HOLE BIDET FITTING WITH METAL CROSS HANDLES (STYLE No. HNBFO1, HN01BF)</u>. All dimensions are based on original specification and are subject to change and variation. Please consult your Design Associate for current specifications.

Installation Guidelines

INSPECT THE INSTALLATION:

12. Unthread the aerator housing to remove the aerator and rubber washer, see Figure - 03.





FIGURE - 03

- 13. Carefully open the hot and cold valves to flush out any debris in the supply lines and inspect all connections for leaks.
- 14. Close the drain and fill the bidet with water to make sure the drain stopper operates and seals properly.
 - a) To adjust the height of the drain stopper, turn the adjustment screw at the base of the stopper and then tighten the locking nut to secure.



- b) The linkage position will affect drain stopper function, adjust as needed.
- 15. Close the valves and re-install the aerator.
- If further assistance is required, please contact Product Support at 1-800-927-2120 Monday through Friday, 8am-6pm EST.
- Refer to the separate Service Parts Document for available replacement parts.

WATERWORKS

TAILPIECE