
UNIVERSAL

1-3/8" Cylindrical Body Spray

Style No.UNBS13



SPECIFICATIONS: Connection Type: 1/2" Male NPT Recommended Pressure: 45psi Restricted Maximum Flow Rate:1.0 gpm.[3.8 L/min] Rough-in Depth: 3/8" MIN - 3/4" MAX [10mm MIN - 19mm MAX]

IMPORTANT:

- A diverter or wall valve (sold separately) control on/off/volume and must be installed for each fitting that will have water flowing to it.
- To ensure this product is installed properly, you must read and follow these guidelines.
- > The owner/user of this product must keep this information for future reference.
- Be sure your installation conforms to federal, state, and local codes. In the State of Massachusetts, all installations must comply with the rules and regulations set forth within 248 CMR.
- This product must be installed by a professional licensed contractor and must be onsite prior to rough-in, this allows the installer to visualize the installation.
- Inspect this product to ensure you have all the parts required for proper installation.
- Use only a strap wrench or protected/smooth-jaw wrench on any finished surface.
- The use of certain plumber's putty can stain stone or tile surfaces

BODY SPRAY INSTALLATION:

- See Figure 1 & Figure 2 for Steps 1& 2.
- Determine the ideal location for the BODY SPRAY(S) and make sure the female connection is 3/8" MIN to 3/4" MAX from the finished wall.

These guidelines have been prepared for the professional contractor to aid in the installation of: <u>UNIVERSAL 1-3/8" CYLINDRICAL BODY SPRAY (STYLE# UNBS13)</u> All dimensions are based on original specification and are subject to change and variation. Please consult your Design Associate for current specifications.

INSTALLATION GUIDELINES

- 2. Thread the ADAPTER into the female fitting, using an 8mm Allan key.
- 3. Slide the ESCUTCHEON onto the ADAPTER, making sure the GASKET is behind. And then thread the BODY SPRAY HEAD onto the adapter.




FIGURE - 02

INSPECT THE INSTALLATION:

- 4. Remove the body spray head from the adapter. Turn on the wall valve/diverter (sold separately) to flush out any debris in the supply line.
- NOTE: There is a filter located in the body spray head that should be cleaned if there is a loss in performance.
- 5. Inspect all connections for leaks.
- 6. Turn off supply and re-attach the body spray headto the adapter.
- If further assistance is required, please contact Product Support at 1-800-927-2120 (8am-6pm EST).
- See service part document for parts ordering, available on WATERWORKS.COM

WATERWORKS